



2019 NEW ITEMS MAY

RELEASING: 6 LATE MODEL HEATER CORES

The heater core is responsible for warming the air used to operate your vehicle's heating and defrosting functions. It circulates hot coolant from the engine to the cabin in order to warm the air inside the vehicle.

When a repair is needed, choose a quality aftermarket heater core. ProSource Heater Cores™ are designed to match O.E. fit, form and function.

Our products are engineered and tested to provide years of trouble-free operation. Backed by over 50 years of mobile A/C experience, fix it once and fix it right with ProSource.



P/N 92344
VIO 194,054
(07-04) Toyota Highlander



P/N 92345
VIO 89,780
(05-98) Mercedes ML Class



P/N 96103
Volvo w/ Behr Main Unit
O.E.: 85120277



P/N 96105
Navistar
O.E.: 3542604C2, -C3



P/N 96104
Navistar Lone Star, Prostar
Sleeper
O.E.: 3599598-C1



P/N 96106
Mack w/ Behr Main Unit
O.E.: 3543-K0762

Don't forget to test for Electrolysis!

Aluminum heater cores fail due to:

- Erosion from high flow rate
- Contaminated coolant
- Poor quality coolant

Electrolysis is a process of chemical changes in the cooling system where ions exchange between the heater core and engine coolant. This results in a breakdown of the heater core material, leaving a pinhole size leak at or within the heater core. This is usually caused by not properly maintaining the cooling system.